SLIMLINE PHONE

Model: TM902



PLEASE READ THIS USER MANUAL COMPLETELY BEFORE OPERATING THIS UNIT AND RETAIN THIS BOOKLET FOR FUTURE REFERENCE.

Main Features

* New call indicator
* 1 group one-touch memories
* 10 groups two-touch memories
* Flash, Store function
* Mute function
* Redial last number function
* Ringer LO/HI switch
* Desk or wall mountable

Telephone operation

1. Making a call----Lift the handset and press the key pad to have calls.
2. Receiving a call----When the phone rings, lift the handset to receive the calls
3. Ending a call----While a call is active, hang up the handset.
4. Ringer volume----Slide the [Ringer] switch to[HI] for high volume or [LO] for low volume.
5. Redial----To redial the last number called, pick up the handset and press [flash] button (or after one on and off hook process), then press [redial] button. The last number you called can be redialed automatically.
6. Flash----[flash] button is designed to temporarily disconnect the phone line. After press the Flash key, the dialer will send flash signal, and it has 100/300/600ms for choosing. To press [redial] button after the [flash] button , redial the last group number.
7. Mute----To place a call in mute, press the [Mute] button while a call is active, then the calls will be muted for several seconds then return to normal .

Memory Dialing

This telephone can store up to 1 groups one touch memory number and 10 groups two touch memory numbers (up to 16 digits), which will remain stored in memory unless you erase or change them by entering other numbers, or unplug your telephone from the wall jack.

To store One-Touch Dialing Memories:

1. Lift the handset .
2. Press the [store]button.
3. Press the phone number you would like to store.
4. Press the [store]button
5. Press a number from [M1] for the memory location where you would like to store the phone number.
6. The number will be stored in [M1].

To store Two-Touch Dialing Memories:

1. Lift the handset .
2. Press the [store]button.
3. Press the phone number you would like to store.
4. Press the [store]button
5. Press a number from [0~9] for the memory location where you would like to store the phone number.
6. The number will be stored in [0~9].

To dial out from the memory(one-touch):

1. Lift the handset and listen for a dial tone.
2. Press the [M1] button.
3. The number stored in [M1] will be dialed automatically.

To dial out from the memory (two-touch) :

1. Lift the handset and listen for a dial tone.
2. Press[Auto] and press the store location ([1],[2].....[9],[0]) to dial the memory number.
3.The number stored in ([1],[2].....[9],[0]) will be dialed automatically.